

## 'AQ' SINGLE ENTRY FITTING INSTRUCTIONS

1. Fit the shower tray ensuring it is level across all areas (Fig 1).

Apply silicone sealant to the edges of the tray before and after tiling.

**USE THE BOTTOM RAIL TO CHECK THAT THE TRAY IS COMPATIBLE WITH THE ENCLOSURE**

2. Assemble the frame by fixing the top & bottom rails to the fixed glass panel by firstly slackening off the glazing bar (Fig 2). Place the rails over the glass and fix into position using the 40mm screws (Fig 3). Re-tighten the glazing bar and fix the side rail onto the opposite side to complete the assembly of the frame.

4. Fit the rubber door stops using the 10mm round headed screws (Fig 4).

5. Place the wall posts onto both sides of the frame (Fig 5) and lift the complete enclosure into position on the shower tray (Fig 6). Mark the positions of the wall posts and remove the enclosure from the shower tray. Making sure the wall posts are plumb (Fig 7), mark the hole positions (Fig 8), remove and drill for the wall plugs. Fit the wall plugs.

6. Slide the wall posts onto either end of the frame. Carefully, lift the frame into position and fix to the wall using the 30mm screws. Ensure that the screw collars are fitted to the screw beforehand. Taking care not to scratch the unit, mark and drill two 3.2mm holes 150mm from the top & bottom on the inside of the enclosure through the wall posts and frame (Fig 9). Secure with the 10mm screws, again ensuring that the collars are in place.

7. Fix the top wheels to the glass door ensuring the correct hand for installation by unclipping and lowering the cover cap. Undo the retaining nut and fix through the hole in the glass and re-tighten (Fig 10). Final adjustment can be made by slackening the nut when the assembly is complete.

8. Fix the bottom wheels into position by dis-assembling the wheel and placing the plastic saddle over the glass. Tighten in position through the hole in the glass. Place the spring over the spigot within the wheel housing (Sketch A) and slide the wheel onto the plastic sandle. Re-fit the cover cap (Fig 11).

If the door does not run true, final adjustment can be made by adjusting the top wheels. Slacken the retaining nut and adjust up and down accordingly. Re-tighten the nut.

9. Hang the doors onto the top rail making sure that the wheels are located in the channel (Fig 12). Then from the outside, push down on the spring loaded wheels and clip into position (Fig 13).

10. Cut to length the magnetic strip and seal. Slide the magnetic strip into the side rail and clip the magnetic seal onto the door ensuring the offset marries up with the magnetic strip. Cut to length the two vertical water seals and clip into position on the glass doors and the glass side panels (Fig 14/15).

12. Finish by fitting the handles, decorative caps supplied and apply silicone down the vertical edges of the wall channel, and the bottom edge between the bottom rail and tray (Fig 15/16). **DO NOT SEAL THE ENCLOSURE ON THE INSIDE OF THE ENCLOSURE!**

Fig. 1



Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6




Fig. 7



Fig. 8




Fig. 9



Fig. 10



Fig. 11




Fig. 12




Fig. 13



Fig. 14





Fig. 15

















Fig. 16



# AQ SINGLE ENTRY FITTING INSTRUCTION



AF SINGLE ENTRY PARTS LIST		
	MAGNETIC STRIP	1
	MAGNETIC SEAL	1
	VERTICAL SEAL	2
	SCREW COLLAR	10
	SCREW COVER CAPS	10
	RUBBER DOOR STOP	2
	WALL PLUGS	6
	40mm SCREWS	8
	30mm SCREWS	6
	10mm R/H SCREWS	6
	10mm C/S SCREWS	2
	BOTTOM WHEEL ASSEMBLY	2
	TOP WHEEL ASSEMBLY	2
	WALL POST COVER CAPS	2
	DOOR HANDLE	1